

Key Features: (A723G)


- 7-inch IPS touch screen, 16:9 widescreen (WSVGA 1024*600)
- INTEL® ATOM™ x3-C3230RK Quad Core 1.2GHz 64-bitz Processor
- 1GB of RAM, 8GB FLASH Memory
- Browse the web, watch YouTube videos, check e-mail and much more with Android 5.1
- Connect to the Internet wirelessly with high-speed networking support (Wi-Fi 802.11b/g/n) or 3G Network
- Plays popular video, music and photo formats
- Application marketplace to download and enjoy popular games and apps
- E-book Reader: Download and read thousands of books
- Expandable memory to 32GB with optional micro SDHC card
- View pages in portrait or landscape with automatic orientation sensor
- For more detailed information, refer to the user manual on the device's main apps interface.



Tablet PC



Adaptor AC/DC




Quick Setup Guide



USB Cable



Warranty card



* Recovery Function - This function erases all user data and bring the tablet to factory setting.

1. Power Off
2. Press and hold (about 12 seconds) Power and Volume Down (-) buttons.
3. Keep holding the 3 buttons until see a menú with for Android system recovery options.
4. Navigate with Volume Up (+) and Volume Down (-) buttons to select options.
5. Press Power button to select option.